


# HUNTER - CRESTFIELD - CEILING FAN ACCESSORIES GUIDE

## Installing the Pull Chains



Repeat x2


### Note:

Fan style may vary.

The fan pull chain controls the speed: from high to off.

The light pull chain controls the light fixture: on and off.

## Reversing the Fan



### Note:

Fan style may vary.