

HUNTER - CASSIUS - CEILING FAN WIRING AND LIGHTING GUIDE


Wiring the Fan

We know wiring is hard. Let's make it easier.

Follow these steps to get your fan wired quickly and safely. Follow the route below that best matches your wall switch setup. If you are unfamiliar with wiring or uncomfortable doing it yourself, please contact a qualified electrician.

You are going to need these:

4 Wire Nuts (these are in the * bag)







Hunter Pro Tip:

Turn the wires upward and push them carefully back through the hanger bracket into the outlet box. Spread the wires apart, with the grounded wires on one side of the outlet box and the ungrounded wires on the other side of the outlet box. Make sure that the wires are still attached to the wire nuts.

Hanging Fan Upper Switch Housing
















HUNTER - CASSIUS - CEILING FAN INSTALLATION GUIDE



















HUNTER - CASSIUS - CEILING FAN INSTALLATION GUIDE

Assembling the Light Fixture 2 of 3 1 of 3 Light Kit Screw Partially install two light kit assembly screws, found in the = hardware bag, halfway into the motor AID. housing as shown. It does not matter which two screw holes you choose Insert the third screw, found in the hardware bag, into place and then tighten all Feed the wire plug through the center hole of the upper three screws switch housing, then wrap keyhole slots around the WARNING FAN FALL HAZARD Make sure all three screws are tight to secure the trim ring to the mounting plate.





Note:
Fan style may vary.

Ceiling Bracket Downrod Hanging Fan Wiring Canopy Blades Upper Switch Housing Reverse **8**











