



# HUNTER - DEMPSEY - CEILING FAN INSTALLATION GUIDE

### What to Expect with Your Installation

Must be able to secure the fan to building structure or fan-rated outlet box

If you are unfamiliar with wiring, use a qualified electrician.

Know your wiring

Assess location

You may need a friend to help you.

Check box to see fan weight

www.HunterFan.com 1.888.830.1326

### Read and Save These Instructions

This product conforms to UL Standard 507.

#### ⚠ WARNINGS

w.1 - To reduce the risk of fire, electrical shock, or personal injury, mount fan directly from building structure and/or an outlet box marked acceptable for fan support of 70 lbs (31.8 kg) and use the mounting screws provided with the outlet box.

w.2 - To avoid possible electrical shock, before installing or servicing your fan, disconnect the power by turning off the circuit breakers to the outlet box and associated wall switch location. If you cannot lock the circuit breakers in the off position, securely fasten a prominent warning device, such as a tag, to the service panel.

w.3 - To reduce the risk of fire, electrical shock, or motor damage, use only Hunter Solid State Speed Controls.

w.4 - To reduce the risk of personal injury, do not bend the blade brackets when installing the blade brackets, balancing the blades, or cleaning the fan. Do not insert foreign objects in between rotating fan blades.

#### ⚠ CAUTIONS

c.1 - All wiring must be in accordance with national and local electrical codes ANSI/NFPA 70. If you are unfamiliar with wiring, use a qualified electrician.

c.2 - Use only Hunter replacement parts.

*This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*Caution: modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.*

*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.*

2

M0117-01 • 02/12/16 • © 2016 Hunter Fan Company



#2 Chootoo Road, South Aranguez, San Juan, Trinidad








# HUNTER - DEMPSEY - CEILING FAN INSTALLATION GUIDE


**Tools Needed**


[www.HunterFan.com](http://www.HunterFan.com) 1.888.830.1326


☒   
Ladder

☒   
Pliers

☒   
Wire Strippers

☒   
Screwdrivers

☐   
Power Drill  
(optional)

☐   
9/64" Drill Bit  
(optional)

If mounting to a support structure, you will also need these tools.

3

M0117-01 • 02/12/16 • © 2016 Hunter Fan Company



#2 Chootoo Road, South Aranguez, San Juan, Trinidad





# HUNTER - DEMPSEY - CEILING FAN INSTALLATION GUIDE

**Ceiling Plate**

www.HunterFan.com 1.888.830.1326

**Turn Power OFF**

**Bumper**

Make sure all four bumpers are still attached.

Use wood screws (included) when securing to support structure with approved electrical outlet box. Drill 9/64" pilot holes in support structure to aid in securing ceiling plate with hardware found in the ★ hardware bag.

To avoid possible electrical shock, before installing your fan, disconnect the power by turning off the circuit breakers to the outlet box associated with the wall switch location.

Refer to warning w.1 on pg. 2

4

M0117-01 • 02/12/16 • © 2016 Hunter Fan Company




#2 Chootoo Road, South Aranguez, San Juan, Trinidad






# HUNTER - DEMPSEY - CEILING FAN INSTALLATION GUIDE


**Top Housing** [www.HunterFan.com](http://www.HunterFan.com) 1.888.830.1326




Thread the wires through the top housing.



Place the top housing onto the motor housing so that the holes in the top housing lineup with the holes in the motor housing and the adapter.



Rest the trim ring on the top housing.



Place the canopy on the top housing. Ensure all four screw holes line up with the screw holes in both the top housing and the adapter.

M0117-01 • 02/12/16 • © 2016 Hunter Fan Company




#2 Chootoo Road, South Aranguéz, San Juan, Trinidad





# HUNTER - DEMPSEY - CEILING FAN INSTALLATION GUIDE




#2 Chootoo Road, South Aranguez, San Juan, Trinidad





# HUNTER - DEMPSEY - CEILING FAN INSTALLATION GUIDE


**Hanging the Fan**
www.HunterFan.com 1.888.830.1326



Ceiling Plate Hook


Raise the fan and align the slots in the canopy with the hooks on the ceiling plate.

**Note:** To hang the fan, you must tilt the canopy to an almost vertical position so that the canopy slots sit on the ceiling plate hooks.



Ceiling Plate Hook

Place the slots over the ceiling plate hooks to hang the fan.



**Note:** Fan style may vary.

7

M0117-01 • 02/12/16 • © 2016 Hunter Fan Company



#2 Chootoo Road, South Aranguez, San Juan, Trinidad

