



# HUNTER - DEMPSEY - CEILING FAN WIRING AND LIGHTING GUIDE

## Wiring the Fan



**We know wiring is hard. Let's make it easier.**

Follow these steps to get your fan wired quickly and safely. Follow the route below that best matches your wall switch setup. If you are unfamiliar with wiring or uncomfortable doing it yourself, please contact a qualified electrician.

### Hunter Pro Tip:

**Here is how to connect the wires:**


Push the bare metal ends of the wires together and slide a wire nut over them. Then, twist the wire nut clockwise until tight. Give it a gentle pull to make sure none of the wires are loose.



### Hunter Pro Tip:

**Have extra wiring?**

Turn the wires upward and push them carefully back through the hanger bracket into the outlet box. Make sure that the wires are still attached to the wire nuts.



Ceiling Bracket Hanging Fan Wiring Canopy Blades Light Glass Remote Troubleshooting Downrod

6




#2 Chootoo Road, South Arangué, San Juan, Trinidad




# HUNTER - DEMPSEY - CEILING FAN WIRING AND LIGHTING GUIDE

## Installing the Canopy




Lift the canopy into place so that the screw holes are aligned.

Insert the two canopy screws found in the ● hardware bag.




Fit the canopy in place as shown.

## Installing the Blades:



Attach each blade to a blade iron using three blade washers, found in the ■ hardware bag, and three blade assembly screws, found in the ▲ hardware bag.

**Repeat x4**



**Note:**  
Fan style may vary.

# HUNTER - DEMPSEY - CEILING FAN INSTALLATION GUIDE

## Assembling the Light Kit

